

**Payment Pebble compatible devices as at 18 November 2016**

Device Type	Device Manufacturer	Device Model	Operating system
Apple	iPhone 3GS up to 6 ( <i>iPhone 7 currently not supported do to audio jack requirement</i> )		iOS Software version 6 or above
	iPad 2 or above		
	iPad mini		
	iPad Air		
Android	<b>Payment Pebble Handset</b>	<b>Absa</b>	Android Software version 2.3.3 or above
Android	HUAWEI	ALE-L21	Android Software version 2.3.3 or above
Android	HUAWEI	G7-L01	Android Software version 2.3.3 or above
Android	HUAWEI	HUAWEI Y221-U12	Android Software version 2.3.3 or above
Android	HUAWEI	HUAWEI Y330-U01	Android Software version 2.3.3 or above
Android	HUAWEI	HUAWEI Y560-L01	Android Software version 2.3.3 or above
Android	HUAWEI	MediaPad 7 Youth 2	Android Software version 2.3.3 or above
Android	HUAWEI	Y220-U00	Android Software version 2.3.3 or above
Android	LGE	LG-D722	Android Software version 2.3.3 or above
Android	LGE	LG-D855	Android Software version 2.3.3 or above
Android	LGE	LG-H635	Android Software version 2.3.3 or above
Android	LGE	LG-H735	Android Software version 2.3.3 or above
Android	LGE	LG-H815	Android Software version 2.3.3 or above
Android	LGE	LG-H850	Android Software version 2.3.3 or above
Android	samsung	GT-I8190	Android Software version 2.3.3 or above
Android	samsung	GT-I8200	Android Software version 2.3.3 or above
Android	samsung	GT-I9060	Android Software version 2.3.3 or above
Android	samsung	GT-I9060I	Android Software version 2.3.3 or above
Android	samsung	GT-I9100	Android Software version 2.3.3 or above
Android	samsung	GT-I9190	Android Software version 2.3.3 or above
Android	samsung	GT-I9195	Android Software version 2.3.3 or above
Android	samsung	GT-I9195I	Android Software version 2.3.3 or above
Android	samsung	GT-I9295	Android Software version 2.3.3 or above
Android	samsung	GT-I9300	Android Software version 2.3.3 or above
Android	samsung	GT-I9305	Android Software version 2.3.3 or above
Android	samsung	GT-I9500	Android Software version 2.3.3 or above
Android	samsung	GT-I9505	Android Software version 2.3.3 or above
Android	samsung	GT-N5100	Android Software version 2.3.3 or above
Android	samsung	GT-N7100	Android Software version 2.3.3 or above
Android	samsung	GT-N8000	Android Software version 2.3.3 or above
Android	samsung	GT-N8020	Android Software version 2.3.3 or above
Android	samsung	GT-P3100	Android Software version 2.3.3 or above
Android	samsung	GT-P5100	Android Software version 2.3.3 or above
Android	samsung	GT-P5200	Android Software version 2.3.3 or above
Android	samsung	GT-P5220	Android Software version 2.3.3 or above
Android	samsung	GT-P7500	Android Software version 2.3.3 or above
Android	samsung	GT-S6790	Android Software version 2.3.3 or above
Android	samsung	GT-S7580	Android Software version 2.3.3 or above
Android	samsung	SM-A300F	Android Software version 2.3.3 or above
Android	samsung	SM-A300FU	Android Software version 2.3.3 or above
Android	samsung	SM-A310F	Android Software version 2.3.3 or above
Android	samsung	SM-A500F	Android Software version 2.3.3 or above
Android	samsung	SM-A500FU	Android Software version 2.3.3 or above
Android	samsung	SM-A510F	Android Software version 2.3.3 or above
Android	samsung	SM-A700F	Android Software version 2.3.3 or above
Android	samsung	SM-C101	Android Software version 2.3.3 or above
Android	samsung	SM-G130H	Android Software version 2.3.3 or above
Android	samsung	SM-G313H	Android Software version 2.3.3 or above
Android	samsung	SM-G360H	Android Software version 2.3.3 or above
Android	samsung	SM-G800F	Android Software version 2.3.3 or above
Android	samsung	SM-G800H	Android Software version 2.3.3 or above
Android	samsung	SM-G900F	Android Software version 2.3.3 or above
Android	samsung	SM-G900H	Android Software version 2.3.3 or above
Android	samsung	SM-G920F	Android Software version 2.3.3 or above
Android	samsung	SM-G925F	Android Software version 2.3.3 or above
Android	samsung	SM-G928C	Android Software version 2.3.3 or above
Android	samsung	SM-G928F	Android Software version 2.3.3 or above
Android	samsung	SM-G930F	Android Software version 2.3.3 or above
Android	samsung	SM-G935F	Android Software version 2.3.3 or above
Android	samsung	SM-J100H	Android Software version 2.3.3 or above
Android	samsung	SM-J105F	Android Software version 2.3.3 or above
Android	samsung	SM-J110F	Android Software version 2.3.3 or above
Android	samsung	SM-J111F	Android Software version 2.3.3 or above
Android	samsung	SM-J120F	Android Software version 2.3.3 or above
Android	samsung	SM-J320FN	Android Software version 2.3.3 or above
Android	samsung	SM-J500F	Android Software version 2.3.3 or above
Android	samsung	SM-N9005	Android Software version 2.3.3 or above
Android	samsung	SM-N910C	Android Software version 2.3.3 or above
Android	samsung	SM-N910F	Android Software version 2.3.3 or above
Android	samsung	SM-N910H	Android Software version 2.3.3 or above
Android	samsung	SM-N915F	Android Software version 2.3.3 or above
Android	samsung	SM-N920C	Android Software version 2.3.3 or above
Android	samsung	SM-P555	Android Software version 2.3.3 or above
Android	samsung	SM-P605	Android Software version 2.3.3 or above
Android	samsung	SM-T116	Android Software version 2.3.3 or above
Android	samsung	SM-T211	Android Software version 2.3.3 or above
Android	samsung	SM-T231	Android Software version 2.3.3 or above

**Payment Pebble compatible devices as at 18 November 2016**

Device Type	Device Manufacturer	Device Model	Operating system
Android	samsung	SM-T531	Android Software version 2.3.3 or above
Android	samsung	SM-T535	Android Software version 2.3.3 or above
Android	samsung	SM-T561	Android Software version 2.3.3 or above
Android	samsung	SM-T815	Android Software version 2.3.3 or above
Android	Sony	C6603	Android Software version 2.3.3 or above
Android	Sony	C6903	Android Software version 2.3.3 or above
Android	Sony	D2203	Android Software version 2.3.3 or above
Android	Sony	D2303	Android Software version 2.3.3 or above
Android	Sony	D2403	Android Software version 2.3.3 or above
Android	Sony	D2502	Android Software version 2.3.3 or above
Android	Sony	D2533	Android Software version 2.3.3 or above
Android	Sony	D5803	Android Software version 2.3.3 or above
Android	Sony	D6503	Android Software version 2.3.3 or above
Android	Sony	D6603	Android Software version 2.3.3 or above
Android	Sony	E2003	Android Software version 2.3.3 or above
Android	Sony	E5603	Android Software version 2.3.3 or above
Android	Sony	E5823	Android Software version 2.3.3 or above
Android	Sony	E6653	Android Software version 2.3.3 or above
Android	Sony	LT25i	Android Software version 2.3.3 or above
Android	TCT	ALCATEL ONE TOUCH 7041X	Android Software version 2.3.3 or above
Android	TCT	ALCATEL ONE TOUCH P310X	Android Software version 2.3.3 or above
Android	Vodafone	VF685	Android Software version 2.3.3 or above
Android	Vodafone	VF695	Android Software version 2.3.3 or above
Android	Vodafone	VFD 1100	Android Software version 2.3.3 or above
Android	Vodafone	VFD 300	Android Software version 2.3.3 or above
Android	Vodafone	Vodacom Power Tab 10	Android Software version 2.3.3 or above
Android	Vodafone	Vodafone 785	Android Software version 2.3.3 or above
Android	Vodafone	Vodafone Smart Tab 3G	Android Software version 2.3.3 or above